

LEGEND

MAP UNIT (HYDROGEOMORPHIC UNIT) REPRESENTED IN THE MAP WITH ALPHANUMERIC CODE (COLOUR INDICATES YIELD RANGE AND HATCHING INDICATE DEPTH RANGE)	GEOLOGICAL SEQUENCE / ROCK TYPE (REPRESENTED IN THE MAP WITH NUMERIC CODE)	GEOMORPHIC UNIT / LANDFORM (REPRESENTED IN THE MAP WITH ALPHABETIC CODE)	DEPTH TO WATER LEVEL PRE / POST-MONSOON (AVERAGE IN METERS) NO. OF WELLS OBSERVED	RECHARGE CONDITIONS BASED ON AVAILABILITY OF WATER (RAINFALL & OTHER SOURCES)	GROUND WATER PROSPECTS							RECHARGE STRUCTURES	
					AQUIFER MATERIAL LS = LOOSE SEDIMENTS PR = PERMEABLE ROCK FIR = FISSURED ROCK FR = FRACTURED ROCK WR /= WEATHERED ROCK / WM WEATHERED MATERIAL IR = IMPERVIOUS ROCK IM = IMPERVIOUS MATERIAL	TYPE OF WELLS SUITABLE DW = DUG WELL RW = RING WELL BW = BORE WELL TW = TUBE WELL DBW /= DUG CUM-BORE WELL / DTW DUG CUM-TUBE WELL	DEPTH RANGE OF WELLS (SUGGESTED) MIN - MAX (IN METERS)	YIELD RANGE OF WELLS (EXPECTED) (in LPM or m ³ /day)	HOMOGENEITY IN THE UNIT & SUCCESS RATE OF WELLS (PROBABILITY) VERY HIGH HIGH MODERATE LOW	QUALITY OF WATER POTABLE (P) NON - POTABLE (NP) (INDICATE REASONS IF NON POTABLE)	GROUND WATER IRRIGATED AREA (APPROX. RANGE IN PERCENTAGE)	SUITABLE & PRIORITY PT = PERCOLATION TANK CD = CHECK DAM NB = NALA BUND RW = RECHARGE WELL DT = DESILITING OF TANK RP = RECHARGE PIT SD = SUBSURFACE DYKE RS = RECHARGE SHAFT ST = STORAGE TANK SCM = SOIL CONSERVATION MEASURE	REMARKS (PROBLEMS / LIMITATIONS)
CB111	Hugli/Bhagirathi Formation (Present Day) (11) (11)	Channel Bar (CB)	<u>5 - 6</u> 2	Excellent	LS	TW	5-10 m	400-500 LPM	Very High	Р	42%	Not Required	Groundwater prospects very high with high recharge potential. Recharge structures not required.
APY113	Pan Skura Skura Holocene) (Early to Late Holocene) (Early to Late Holocene) (Early to Late Holocene)	Alluvial Plain Younger (APY)	2.62 - 6.84 DW - 5	Very Good	LS	DW TW	10 - 12 m 20 - 30 m	125 - 150 m /day 200 - 250 LPM	Very High	Р	20%	Not Required	Aquifer is formed of Sandy part of alluvium. Recharge structures not required as good recharge conditions prevail
APO13	Sijua Formation (Late Pleistocene to Early Holocene) (13) (13) (13)	Alluvial Plain Older (APO)	1.79 ————————————————————————————————————	Good	LS	DW TW	10 - 20 m 40 - 60 m	80 - 100 m ³ /day 150 - 200 LPM	High	Р	Nil	Not Required	Aquifer is formed of Sandy part of alluvium. Recharge structures not required as good recharge conditions prevail
VFS211	(Middle to Upper Pleistocene) (Middle to Upper Pleistocene) (State ite (Learn at ion page 1) (211) (State ite (Learn at ion page 2) (211) (State ite (Learn at ion	Valley Fill Shallow (VFS)	No wells observed	Moderate	LS Underlain by WM+FR	TW / BW	50 - 60 m	75 - 100 LPM	Moderate	Р	40%	DT Moderate	Recharge structures will increase the sustainability of groundwater
LP211		Lateritic Plain (LP) (Lithomarge Clay)	2.2 - 9.4 DW - 35	Limited	WM+FR	DW TW / BW	15 - 20 m 50 - 60 m	25 - 50 m ³ /day 50 - 100 LPM	Moderate	Р	Nil	RW / DT High	Areas of exposed lithomarge clay. Fracture zones form the aquifer, recharge structure will enhance groundwater development
DLU211		Dissected Lateritic Upland (DLU) (Hard crust and Lateritic nodules)	3.75 - 6.15 ————————————————————————————————————	Nil to moderate	WM+IR (Impervious material)	TW / BW	80 - 100 m	30 - 50 LPM	Low	Р	Nil	Not Required	Essentially run-off zone where hard capping is present. Areas of nodular laterites are recharge zones with deep water table conditions. Primarily forest areas with sparse settlements. Not sui for large scale development of ground
BPS512	Sandstone (Supra Panchet) (Mahadeva Formation) (512)	Buried Pediplain Shallow (BPS)	No wells observed	Moderate	WM+FR	DW TW / BW	5 - 10 m 40 - 60 m	15 - 25 m ³ /day 75 - 100 LPM	Low	Р	Nil	RP / DT High	Weathered and Fractured Standstone form the aquifer.Better prospects along fracture zones
BPM 55	Candwana Carboniferous to Jurassic) Carboniferous to Jurassic) Shale with Sandstone Bands (Panchet Formation) (55)	Buried Pediment Medium (BPM)	No wells observed	Moderate	WM+FR	DW TW / BW	15 - 20 m 40 - 50 m	50 - 60 m ³ /day 100 - 125 LPM	Moderate	Р	Nil	Not Required	Township area, .Areas of piped water supply
BPS55		Buried Pediplain Shallow (BPS)	No wells observed	Limited	WM+FR	DW TW / BW	15 - 20 m 40 - 60 m	5 - 10 m ³ / day 50 - 100 LPM	Low	Р	Nil	Not Required	Township area, .Areas of piped water supply
BPS531	Sandstone & Shale with Coal (Raniganj Formation) (531)	Buried Pediplain Shallow (BPS)	No wells observed	Moderate	WM+FR	DW TW / BW	5 - 10 m 20 - 30 m	10 - 15 m ³ /day 30 - 50 LPM	Low	Р	Nil	Not Required	Aquifer conditions modified by coal mi activities.Groundwater development m not be sustainable in the long run. Areas of piped water supply
BPS832	Guanagpur Guess Complex Guilly (2400 mill.yrs) (832) (832)	Buried Pediplain Shallow (BPS)	4.45 ———————————————————————————————————	Limited	WM+FR	DW TW / BW	5 - 10 m 40 - 60 m	10 - 15 m ³ /day 75 - 100 LPM	Low	Р	50%	RP High	Recharge Structures will improve sustainability of groundwater sources

These are fault / fracture zones, which generally act as conduits for movement of ground water in hard rocks. Along these zones, the yields are significantly higher and wells are likely to be sustainable for longer duration. However, the inferred fractures need to be confirmed by detailed ground surveys.

D_D /Q Q P_P P P P These are dykes, quartz reefs and pegmatite veins, which generally act as barriers for ground water movement.

N.B.-The depth range and yield range of wells may vary within the unit because of certain inhomogeneities. Fractures/Lineaments which are clearly observed / inferred from the satellite image are indicated on the map. There could be some obscured fractures which also influence the ground water prospects.

Locations of the recharge structures shown in the map are tentative. This map is useful for narrowing down the target zones, and exact location on the ground for wells and recharge structures should be identified based on follow-up ground hydrogeological/geophysical surveys.

